



**Note:** This IBM PC BIOS API call is for DOS/Win16 personality only. Use [Family API](#) for portability.

**Note:** [osFree Macro Library](#) provides macros for most of functions

2022/03/13 05:41 · prokushev · [0 Comments](#)

# Int 13H, AH=05H

## Version

IBM 5150 and higher

## Brief

Format Track

## Family API

none

## Input

- AH = 05h
- AL = number of sectors to format
- CH = track number
- DH = head number
- DL = drive number
- ES:BX → address field buffer (see [format](#))

## Return

- CF set on error
- CF clear if successful
- AH = status (see [status](#))

# Macro

```
INCLUDE BIOS.INC
```

```
@DskFormat 0, 0, 0, offset buf
```

## Notes

- on AT or higher, call AH=17h first
- the number of sectors per track is read from the diskette parameter table pointed at by INT 1E
- some old Compaq BIOSes have a bug when attempting to call this function from Windows Standard Mode with EMM386 loaded. A possible workaround is to call this function from Real Mode e.g. through DPML function "Call Real Mode function with FAR return" (see INT 31/AX=0301h).

## Note

Text based on [Ralf Brown Interrupt List Release 61](#)

IBM PC BIOS API	
Video I/O	<b>INT 10H:</b> 00H, 01H, 02H, 03H, 05H, 06H, 07H, 08H, 09H, 0AH, 0BH, 0CH, 0DH, 0EH, 0FH
Hardware info	<b>INT 11H, INT 12H</b>
Serial I/O	<b>INT 14H:</b> 00H, 01H, 02H, 03H
Tape I/O	<b>INT 15H:</b> 00H, 01H, 02H, 03H
Keyboard I/O	<b>INT 16H:</b> 00H, 01H, 02H
Printer I/O	<b>INT 17H:</b> 00H, 01H, 02H
Disk I/O	<b>INT 13H:</b> 00H, 01H, 02H, 03H, 04H, 05H
Date and Time	<b>INT 1AH:</b> 00H, 01H
osFree Macro Library	
Video I/O	@SetMode @SetCurSz @SetCurPos @GetCur @SetPage @ScrollUp @ScrollDn @Scroll @GetChAtr @PutChAtr @PutCh @SetPalet @SetColor @SetDot @GetDot @WrtTTY @VideoState @GetMode @GetDisplay @GetVideoState @GetEGAInfo @Cls
Hardware info	@Equipment @MemSize
Serial I/O	@AuxInit @AuxSendChar @AuxRecieveChar @AuxStatus
Tape I/O	@TapeOn @TapeOff @TapeRead @TapeWrite
Keyboard I/O	@KbdStatus @CharIn @CharPeek
Printer I/O	@PrnPrint @PrnInit @PrnStatus
Disk I/O	@DskReset @DskStatus @DskRead @DskWrite @DskVerify @DskFormat
Date and Time	@SetTime @GetTime
Mouse	@MouInit @MouShowPointer @MouStatus @MouSetPos @MouSetMickey @MouRegion
Memory manager	@ModBlok SET_BLOCK

2022/10/04 14:28 · prokushev · 0 Comments

2022/03/13 05:54 · prokushev · 0 Comments

Family API		
DOS	Process Manager	DosBeep DosExit DosSleep DosExecPgm
	File Manager	DosChDir DosChgFilePtr DosClose DosDelete DosDupHandle DosMkDir DosMove DosQCurDir DosQCurDisk DosSetFileMode DosOpen DosQFileInfo DosRead DosQFileMode DosQFSInfo DosQVerify DosRmdir DosSelectDisk DosFindClose DosFindFirst DosFindNext DosSetFileInfo DosSetVerify DosWrite DosFileLocks DosSetFHandState DosNewSize DosBufReset DosQFHandState DosSetFSInfo DosShutdown
	Memory Manager	DosFreeSeg DosSubAlloc DosSubFree DosSubSet DosAllocHuge DosAllocSeg DosReallocHuge DosReallocSeg DosGetHugeShift DosCreateCSAlias
	NLS	DosCaseMap DosGetCtryInfo DosGetDBCSEv DosSetCtryCode DosGetCollate DosGetMessage DosInsMessage DosPutMessage
	Date and Time	DosSetDateTime DosGetDateTime
	Devices	DosDevConfig DosDevIOctl DosDevIOctl2
	Signals	DosHoldSignal DosSetSigHandler
	Misc	BadDynLink DosGetEnv DosGetMachineMode DosGetVersion DosError DosErrClass DosSetVec
KBD	KbdCharIn KbdFlushBuffer KbdGetStatus KbdSetStatus KbdStringIn KbdPeek	
VIO	VioGetBuf VioGetConfig VioGetCurPos VioGetCurType VioGetPhysBuf VioReadCellStr VioReadCharStr VioScrollUp VioScrollDn VioScrollLf VioScrollRt VioScrUnLock VioSetCurPos VioSetCurType VioSetMode VioGetMode VioShowBuf VioWrtCellStr VioWrtCharStr VioWrtCharStrAtt VioWrtNAttr VioWrtNCell VioWrtNChar VioWrtTTY VioScrLock VioPopUp	
Tools	BIND	
Modules	DOSCALLS.DLL VIOCALLS.DLL KBDCALLS.DLL MSG.DLL	
Libraries	API.LIB OS2386.LIB FAPI.LIB DOSCALLS.LIB SUBCALLS.LIB	

2018/08/25 15:05 · prokushev · 0 Comments

From:

<https://osfree.su/doku/> - **osFree wiki**

Permanent link:

<https://osfree.su/doku/doku.php?id=en:docs:bios:api:int13:05>Last update: **2023/12/17 05:56**