



**Note:** This IBM PC BIOS API call is for DOS/Win16 personality only. Use [Family API](#) for portability.

**Note:** [osFree Macro Library](#) provides macros for most of functions

2022/03/13 05:41 · prokushev · [0 Comments](#)

## BIOS API

All registers saved on entry and restores on return

### BIOS Interrupts

Interrupt vector	Description	Version
<a href="#">10H</a>	Video I/O	1+
<a href="#">11H</a>	Equipment	1+
<a href="#">12H</a>	Memory size	1+
<a href="#">13H</a>	Diskette I/O	1+
<a href="#">14H</a>	RS232 I/O	1+
<a href="#">15H</a>	Cassette I/O	1+
<a href="#">16H</a>	Keyboard I/O	1+
<a href="#">17H</a>	Printer I/O	1+
<a href="#">18H</a>	ROM BASIC	1+
<a href="#">19H</a>	Bootstrap	1+
<a href="#">1AH</a>	Time of date	1+

From:

<https://osfree.org/doku/> - **osFree wiki**

Permanent link:

<https://osfree.org/doku/doku.php?id=en:docs:bios:api&rev=1640417168>

Last update: **2021/12/25 07:26**

